



## VTRANS DISTRICT BOUNDARIES AND REGIONS

- 1 - Bennington District
- 2 - Dummerston District
- 3 - Mendon District
- 4 - White River Jct. District
- 5 - Colchester District
- 6 - Capital District
- 7 - St. Johnsbury District
- 8 - St. Albans District
- 9 - Derby District
- District Boundary
- Region Boundary
- ★ VTrans Maintenance Bureau HQ
- Maintenance District Office
- Primary Maintenance Facility

Map produced by:  
 Vermont Agency of Transportation, Mapping Section  
 219 North Main Street, Barre, VT 05641  
 Telephone: 802-828-2600